


Twisty



Name	Art.-nr.	Ø	Boden-Ø	Höhe	Länge mit Griff	Gewicht	Deckel (Art.-nr.)
Stielkasserolle Twisty ohne Griff	3491.14	14 cm	12 cm	7 cm	21,5 cm	0,44 kg	4112.14
	3491.16	16 cm	13 cm	8 cm	23,5 cm	0,53 kg	4112.16
	3491.18	18 cm	15,5 cm	9 cm	25,5 cm	0,72 kg	4112.18
	3491.20	20 cm	17,5 cm	10 cm	28 cm	0,85 kg	4112.20
	3491.24	24 cm	20,5 cm	12 cm	32 cm	1,28 kg	4112.24
	3491.28	28 cm	24,7 cm	14 cm	35,5 cm	1,95 kg	4112.28
Satz von 3 Kasserollen ohne Griff	3491.03	16 cm 18 cm 20 cm	13 cm 15,5 cm 17,5 cm	8 cm 9 cm 10 cm	23,5 cm 25,5 cm 28 cm	2,49 kg	4112.16 4112.18 4112.20
Satz von 4 Kasserollen mit schwarzen Silikon-griffen und Stiel	3491.04	14 cm 16 cm 18 cm 20 cm	12 cm 13 cm 15,5 cm 17,5 cm	7 cm 8 cm 9 cm 10 cm	21,5 cm 23,5 cm 25,5 cm 28 cm	3,11 kg	4112.14 4112.16 4112.18 4112.20
Sauteuse Twisty aus Edelstahl	3495.24	24 cm	17,5 cm	8 cm	32 cm	0,98 kg	4112.24
Pfanne Twisty aus Edelstahl	3493.24	24 cm	16 cm	4,8 cm	31,5 cm	0,88 kg	4112.24
	3493.28	28 cm	19 cm	5,3 cm	35,5 cm	1,22 kg	4112.28